2006 ford freestar service manual

Download

Download

Quick Links. Table of Contents. Warning And Control Lights. Entertainment Systems. Climate Controls. Rear Window Defroster. Turn Signal Control. Bulb Replacement. Driver Controls. Steering Wheel Adjustment. Power Windows. Speed Control. Message Center. Locks And Security. Owners Guide postfmt. USA fus. Ford five hundred automobile owner's manual pages. Ford crown victoria automobile owner's manual pages. Ford may change the contents without notice and without incurring obligation. Page 4: Introduction State of California to cause cancer and birth defects or other reproductive harm. Please take the time to get well acquainted with your vehicle by reading this handbook. The more you know and understand about your vehicle, the greater the safety and pleasure you will derive from driving it. Page 5 Do not add friction modifier compounds or special break-in oils during the first few thousand miles kilometers of operation, since these additives may prevent piston ring seating. See Engine oil in the Maintenance and Specifications chapter for more information on oil usage. To access this information, special equipment must be directly connected to the recording modules. Ford Motor Company and Ford of Canada do not access event data recorder information without obtaining consent, If any light remains on after starting the vehicle, refer to the respective system warning light for additional information. A significant decrease in braking performance may occur. It will take you longer to stop the vehicle. Have the vehicle checked by your authorized dealer. Never remove the coolant reservoir cap while the engine is running or hot. Turns off when the speed control system is disengaged. If the indicators stay on or flash faster, check for a burned out bulb. Tachometer: Indicates the engine speed in revolutions per minute. Driving with your tachometer pointer continuously at the top of the scale may damage the engine. Refer to Filling the tank in the Maintenance and Specifications chapter for more information. SEEK Freestar win Owners Guide postfmt USA fus Page 20 When this audio is used in cargo vans where no rear speakers are installed in the vehicle, fading to the rear speakers will result in no audio output. If there are less than six strong stations, the system will store the last one in the remaining presets. Bass: Press to adjust the bass setting. Shuffle: Press to play tracks in random order. Repeat: Press to repeat the current CD track. CD eject: Press to eject a CD. Shuffle: Press to play CD tracks in random order. CD: Press to enter CD mode. If a CD is already loaded into the system, CD play will begin where it ended last. Press again to return to the playing media. Seek: Press to access the next strong station or track. MEM: Press consecutively to scroll through the preset stations, change tape side if equipped , or to change discs on multiple disc radios if equipped. Irregular shaped CDs, CDs with a scratch protection film attached, and CDs with homemade paper adhesive labels should not be inserted into the CD player. Page Climate Controls 5. Use with recirculated air to improve cooling performance and efficiency. Fan speed adjustment: Controls the volume of air circulated in the vehicle. Direct the outer instrument panel vents towards the side windows. Do not place objects on top of the instrument panel as these objects may become projectiles in a collision or sudden stop. REAR: Press to enable the control located in the rear seat. Press again to turn the auxiliary system off. Press again to activate the low heat setting 1 indicator light. Press again to deactivate the passenger heated seat. For more information regarding your filter, see your authorized dealer. Once in the programming mode, the headlamps and parklamps will turn on to indicate the start of the time desired. High beams Push the lever toward the instrument panel to activate. Pull the lever towards you to deactivate. Domelamp Control The panel dimmer control also controls the domelamp operation. The correct bulbs will not damage the lamp assembly or void the lamp assembly warranty and will provide quality bulb burn time. Replacing headlamp bulbs To remove the headlamp bulb: 1. Make sure headlamp switch is in the OFF position, then open the hood. Make sure the headlamp switch is in the OFF position and open the hood. Remove the two headlamp retaining pins to release the headlamp assembly, then pull the headlamp assembly forward to expose the bulb socket. Pull bulb straight out of socket and push in new bulb. Install the new bulb s in reverse order. Replacing high-mount brakelamp bulbs For bulb replacement, see your authorized dealer. Make sure the park lamp switch is in the OFF position and then remove the bulb socket from the supplemental parking lamp by turning counterclockwise. Disconnect the electrical connector. Install the new bulb in reverse order. Adjustments may need to be made to the zone and calibration of the compass. Drive the vehicle in a tight circle in a magnetically clean area such as an open parking lot. Refer to Remote Entry System in the Locks and security chapter. Improper use of the power outlet can cause damage not covered by your warranty. The window will open fully. Momentarily press the switch to any position to stop the window operation. Do not block the sensor on the backside of the inside rear view mirror since this may impair proper mirror performance. Do not use the speed control in heavy traffic or on roads that are winding, slippery or unpaved. This will automatically return the vehicle to the previously set speed. It is also recommended that a new battery be placed in the hand-held transmitter of the device being programmed to HomeLink for

quicker training and accurate transmission of the radio-frequency signal. The indicator light will flash slowly and then rapidly after HomeLink accepts the radio frequency signal. The indicator light will begin to flash after 20 seconds. For questions or comments, contact HomeLink at Displayed when the liftgate is not completely closed. Displayed when the manual park brake is set. If the warning stays on after the park brake is released, contact your authorized dealer as soon as possible. Your oil life is now reset. If you must drive with the liftgate door open, keep the vents open so outside air comes into the vehicle. The PLG can be fully opened by pushing it upward to the maximum open position. Pull up on the liftgate handle to engage the power assist feature. Release the handle as soon as the PLG begins to power open. Do not put more than 50 lbs. The cargo net is not designed to restrain objects during a collision or heavy braking. Loosen the thumbwheel at both ends of the cross-bar both cross-bars are adjustable. Slide the cross-bar to the desired location. Tighten the thumbwheel at both ends of the cross-bar. De-press the metal retention clip located in the inner rail channel on both sides, and slide the crossbar out simultaneously. The interior lamps will illuminate. Insert the new battery. Refer to the diagram inside the remote entry transmitter for the correct orientation of the battery. Press the battery down to ensure that the battery is fully seated in the battery housing cavity. The doors will lock, then unlock, to confirm that this remote entry transmitter has been programmed. The system automatically turns off after 25 seconds. The panel dimmer control must not be set to the off position for the illuminated exit to operate. Repeat this procedure for another remote transmitter if desired. Note: The lock motors will cycle, locked then unlocked. Enter your personal 5-digit code. Each number must be entered within five seconds of each other. The door locks will lock and quickly unlock to confirm programming mode has been exited. The personal code is now erased and only the factory set 5â€"digit code will work. Turn the ignition to the 3 OFF position. The horn will chirp once to confirm the procedure is complete. Use of these systems may result in vehicle starting problems and a loss of security protection. Page 2. Turn ignition from the 4 ON position back to the 3 OFF position in order to remove the first coded key from the ignition. Adjust your head restraint so that it is located directly or as close as possible behind your head. The head restraints can be moved up and down. Lift handle to move seat forward or backward. Pull lever up to adjust seatback. Refer to Front Passenger Sensing System chapter for additional details. Failure to follow these instructions may interfere with the front passenger seat sensing system. For low heat, one light will be lit; for high heat, both lights will be lit. The heating of the seat turns off after 10 minutes or when the vehicle is turned off. Seat mounted cup holders if equipped Deploy by pressing the button on top of the cupholder. Hard objects can injure you in a collision. Adjusting 2nd row seats if equipped Lift control to adjust seat forward or backward. Lift the handle located on the rear lower corner of the seat. The seat back will fold flat. Always latch the vehicle seat to the floor, whether the seat is occupied or empty. If not latched, the seat may cause injury during a sudden stop. Note: Ensure the front row seat is in a forward position to allow the seat to return. Push on the cushion to return the seat. Place seat in tumbled position. See Accessing 3rd row seat 4. From inside the vehicle, pull up on front floor release handle. Rotate the seat rearward at a 30 to 45 degree angle. Position the seat in vehicle. Place first row seat in a forward position to allow the second row seat to be installed. Rotate the seat forward until it latches onto the front pin. Rotate seat rearward until the back of the seat latches onto the floor. Align seat front hooks to the rear most pins of the front tub. Store the tongue of the sliding latchplate in the belt pocket. Push the head restraint release buttons and move the head restraints fully down. Remove all objects from the seat and stowage tub. From the rear of the vehicle, fold seat back by pulling and releasing the number 1 strap. Release the cushion latches by pulling the number 2 strap. Lift the seat out of the tub in the floor by pulling up on the exposed strap or handle. Once seat is at a vertical position, push the seat over, letting it fall onto the latches. When seat is adjusted to desired location, release the strap. The number 1 strap is not used to access this position. Do not sit on the head restraints. Refer to Safety belt section in this chapter. Unless serviced, the system may not function properly in the event of a collision. Always transport children 12 years old and under in the back seat and always properly use appropriate child restraints. How to disengage the automatic locking mode Ford Motor Company recommends that all passenger safety belt assemblies and attaching hardware should be inspected by an authorized dealer after any collision to verify that the automatic locking retractor feature for child seats is still working properly. Also, use the safety belt extension only if the safety belt is too short for you when fully extended. Ford recommends that all safety belt assemblies in use in vehicles involved in a collision be replaced. However, if the collision was Page Airbags All occupants of the vehicle, including the driver, should always properly wear their safety belts, even when an air bag supplemental restraint system SRS is provided. Do not modify the front end of the vehicle. Refer to Side airbag system later in this chapter. The person in the front

passenger seat may appear heavier or lighter due to the conditions described in the list above. The front passenger airbag is not designed to offer protection to an occupant in the center seating position. Page Side airbags, in combination with safety belts, can help reduce the risk of severe injuries in the event of a significant side impact collision. If the airbag is not replaced, the unrepaired area will increase the risk of injury in a collision. To reduce risk of injury, do not obstruct or place objects in the deployment path of the inflatable Safety Canopy. Refer to the Airbag readiness section in the Instrument Cluster chapter. Routine maintenance of the airbag is not required. The passenger cannot protect the child from injury in a collision. Always follow the instructions and warnings that come with any infant or child restraint you might use. Booster seats position a child so that safety belts fit better. They lift the child up so that the lap belt rests low across the hips and the knees bend comfortably. Page top of ear level above the top of the seat. If you do not install and use the safety seat properly, the child may be injured in a sudden stop or collision. Ford recommends the use of a child safety seat having a top tether strap. Pull down on the shoulder belt and then grasp the shoulder belt and lap belt together. Allow the belt to retract. The belt will click as it retracts to indicate it is in the automatic locking mode. Front passenger seating position manual adjusting seats only 1. Position the child safety seat on the passenger seat cushion. Grasp the tether strap and position it to the seat frame. Rotate the tether hook, and clip the tether strap to the seat frame. Follow the instructions in this chapter. For forward-facing child seats, the tether strap must also be attached to the proper tether anchor. See Attaching safety seats with tether straps in this chapter. Check to see if the anchors hold the seat in place. If the safety seat is not anchored properly, the risk of a child being injured in a crash greatly increases. Department of Transportation-Tire quality grades: The U. Department of Transportation requires Ford Motor Company to give you the following information about tire grades exactly as the government has written it. Inflate all tires to the inflation pressure recommended by Ford Motor Company. Use a tire gauge to check the tire inflation pressure, including the spare if equipped , at least monthly and before long trips. Page Always inflate your tires to the Ford recommended inflation pressure even if it is less than the maximum inflation pressure information found on the tire. Page Tire Information For your safety, tires that are damaged or show signs of excessive wear should not be used because they are more likely to blow out or fail. Use of any tire or wheel not recommended by Ford can affect the safety and performance of your vehicle, which could result in an increased risk of loss of vehicle control, vehicle rollover, personal injury and death. Page Have an authorized dealer check the wheel alignment periodically. Wheel misalignment in the front or the rear can cause uneven and rapid treadwear of your tires and should be corrected by an authorized dealer. It is an index that relates to how much weight a tire can carry. If not, contact a local tire dealer. The numbers in between are identification codes used for traceability. This information is used to contact customers if a tire defect requires a recall. The tire suppliers may have additional markings, notes or warnings such as standard load, radial tubeless, etc. Maximum Load Single lb. Refer to the payload description and graphic in the Vehicle loading â€" with and without a trailer section. Failure to properly maintain your tire pressure could increase the risk of tire failure, loss of control, vehicle rollover and personal injury. In short, once the light has turned ON, at least one tire may be underinflated. Check your tire pressure to under-inflated ensure tires are properly inflated; refer to Inflating your tires in this chapter. Ford Motor Company recommends the use of a digital or dial-type tire pressure gauge rather than a stick-type tire pressure gauge for increased accuracy. For these reasons, the low tire pressure warning light is NOT a substitute for using an accurate tire gauge when checking and filling your tires. If you need to use chains, it is recommended that steel wheels of the same size and specifications be used as chains may chip aluminum wheels. Vehicle Curb Weight â€" is the weight of your new vehicle when you picked it up from your authorized dealer plus any aftermarket equipment. Separate functional brakes should be used for safe control of towed vehicles and for trailers where the GCW of the towing vehicle plus the trailer exceed the GVWR of the towing vehicle. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle. See the Tongue Load section in the trailer towing chart earlier in this section for range details on a specific trailer load. Extended idling at high engine speeds can produce very high temperatures in the engine and exhaust system, creating the risk of fire or other damage. Make sure the headlamps and electrical accessories are off. Make sure the gearshift is in P Park. Make sure the parking brake is set. Take precautions to avoid its dangerous effects. If you smell exhaust fumes inside your vehicle, have your dealer inspect your vehicle immediately. Do not drive if you smell exhaust fumes. These are normal characteristics of the ABS and should be no reason for concern. When the system activates, the brake pedal will travel with very little effort; this is normal. If the power steering system breaks

down or if the engine is turned off , you can steer the vehicle manually, but it takes more effort. Refer to Fuses and relays in the Roadside Emergencies chapter. Once the system detects an object approaching, the tone will sound again. Wet brakes do not stop the vehicle as quickly as dry brakes. Page 1â€"â€"â€"; Lincoln vehicle customers call 1â€"â€"â€" Canadian customers who require roadside assistance, call 1â€"â€"â€" If you need to arrange roadside assistance for yourself, Ford Motor Company will reimburse a reasonable amount. To obtain reimbursement information, U. Ford or Mercury vehicles customers call 1â€"â€"â€"; Using a fuse with a higher amperage rating can cause severe wire damage and could start a fire. If the dissimilar spare tire or wheel is damaged, it should be replaced rather than repaired. Locate the access panel on the interior trim. Rotate the panel retaining clip and remove the panel. Remove the jack and lug nut wrench by turning the thumbscrew counterclockwise to relieve tension against the stowage bracket. Stowing the primary tether Note: If no tire is to be stowed under the vehicle, raise the primary tether by turning the wrench clockwise until the hex nut ratchets. Park on a level surface, activate hazard flashers and set parking brake. Place gearshift lever in P Park , turn engine off, and block the diagonally opposite wheel. Remove the spare tire, jack and lug wrench. Loosen each wheel lug nut one-half turn counterclockwise but do not remove them until the wheel is raised off the ground. Locate the jack notch next to the door closest to the tire you are changing, then place the jack on the frame rail directly behind the notch. Page 1. Remove the perforated section of the vinyl mat in the center floor area in order to install the wing screw. Using the tether cable kit located with the jack, pass the cable retainer through center of the wheel. Repeat this tightness check procedure when servicing the spare tire pressure every six months, per Scheduled Maintenance Guide , or at any time that the spare tire is disturbed through service of other components. Use only Ford recommended replacement fasteners. When a wheel is installed, always remove any corrosion, dirt or foreign materials present on the mounting surfaces of the wheel or the surface of the wheel hub, brake drum or brake disc that contacts the wheel. Page Connecting the jumper cables 1. Note: In the illustrations, lightning bolts are used to designate the assisting boosting battery. Connect the negative - cable to the negative - terminal of the assisting battery. Start the engine of the disabled vehicle. Once the disabled vehicle has been started, run both engines for an additional three minutes before disconnecting the jumper cables. Remove the jumper cable from the ground metal surface. After the disabled vehicle has been started and the jumper cables removed, allow it to idle for several minutes so the engine computer can relearn its idle conditions. Do not tow with a slingbelt. Ford Motor Company has not approved a slingbelt towing procedure. If your vehicle is to be towed from the rear using wheel lift, the front wheels must be placed on a dolly to prevent damage to the transaxle. Away from home If you own a Ford or Mercury vehicle and are away from home when your vehicle needs service, or if you need more help than the authorized dealer could provide, after following the steps described above, contact the Ford Customer Relationship Center to find an authorized dealer to help you. Page If you own a Lincoln vehicle and are away from home when your vehicle needs service, or if you need more help than the authorized dealer could provide, after following the steps described above, contact the Ford Customer Relationship Center to find an authorized dealer to help you. Page Customer Assistance In some states in the U. Ford is also allowed a final repair attempt in some states. Page You are not bound by the decision but may choose to accept it. If the arbitrator has decided in Page What kinds of cases does the Board review? Your authorized dealer and a Ford Motor Company representative will then be asked to submit statements. Page United States and Canada, provided by a network of more than 4, participating authorized dealers. If you did not take advantage of the Ford Extended Service Plan at the time of purchasing your vehicle, you may still be eligible. Since this Page The use of leaded fuel in your vehicle without proper conversion may damage the effectiveness of your emission control system and may cause engine knocking or serious engine damage. Page Reporting Safety Defects U. These products may cause premature wearing of the clear, protective coating. These quality products have been specifically engineered to fulfill your automotive needs; Block the wheels. These locations provide two different hood opening positions. Use the location which best suits your needs. Power distribution box 4. Battery 5. Automatic transmission fluid dipstick 6. Engine oil dipstick 7. Engine oil filler cap 8. Windshield washer fluid reservoir 9. Engine coolant reservoir Power steering fluid reservoir Freestar win Owners Guide postfmt USA fus Page Checking and adding washer fluid for the liftgate Washer fluid for the liftgate is supplied by the same reservoir as the windshield. Turn the engine off and wait a few minutes for the oil to drain into the oil pan. Set the parking brake and ensure the gearshift is securely latched in P Park. Open the hood. Protect yourself from engine heat. Refer to Adding engine oil in this chapter. Engine oil and filter recommendations Look for this certification trademark. Ford production and aftermarket Motorcraft oil filters are designed for added engine protection and

long life. If a replacement oil filter is used that does not meet Ford material and design specifications, start-up engine noises or knock may be experienced. Page Wash hands after handling. To account for customer driving habits and conditions, your automatic transaxle electronically controls the shift feel by using an adaptive learning strategy. This feature is designed to optimize shift smoothness. Add the mixture to the coolant reservoir, when the engine is cool, until the appropriate fill level is obtained. Mixing Motorcraft Specialty Orange Engine Coolant or any orange-colored extended life product with your factory filled coolant can result in degraded corrosion protection. Page Recycled engine coolant Ford Motor Company does NOT recommend the use of recycled engine coolant in vehicles originally equipped with Motorcraft Premium Gold Engine Coolant since a Ford-approved recycling process is not yet available. Gasoline may contain benzene, which is a cancer-causing agent. The flow of fuel through a fuel pump nozzle can produce static electricity, which can cause a fire if fuel is pumped into an ungrounded fuel container. Turn off the engine, remove the fuel filler cap, align the cap properly and reinstall it. The fuel system may be under pressure. If the fuel filler cap is venting vapor or if you hear a hissing sound, wait until it stops before completely removing the fuel filler cap. Page Ask your fuel supplier about gasolines that meet the World-wide Fuel Charter. Running out of fuel Avoid running out of fuel because this situation may have an adverse effect on powertrain components. If the fluid is low, add fluid in small amounts, continuously checking the level until it reaches the correct operating range. Be sure to put the cap back on the reservoir. Install the dipstick making sure it is fully seated in the filler tube. Disconnect the Mass Air Flow Sensor electrical connector from the air outlet tube. Reposition the locking clip on the connector and squeeze connector to remove. Remove the air filter element from the air filter housing. Wipe the air filter housing and cover clean to remove any dirt or debris and to ensure good sealing. Reinstall the air cleaner assembly into the vehicle. Ensure the tabs on the inlet tube are secure in the sheet metal. Failure to use the correct air filter element may result in severe engine damage. The customer warranty may be voided for any damage to the engine if the correct air filter element is not used. Replace the PCV valve with one that meets Ford material and design specifications for your vehicle, such as a Motorcraft or equivalent replacement part. The customer warranty may be void for any damage to the emissions system if such a PCV valve is not used. Refer to Lubricant Specifications in this chapter. DOT 3 fluid is recommended. Add the coolant type originally equipped in your vehicle. Page Vehicle line, series, body type 4. Engine type 5. Check digit 6. Model year 7. Assembly plant 8. The following table tells you which transmission or transaxle each code represents. These quality accessories have been specifically engineered to fulfill your automotive needs; they are custom designed to complement the style and aerodynamic appearance of your vehicle. Print page 1 Print document pages. Cancel Delete. Sign In OR. Don't have an account? Sign up! Restore password. Upload from disk. Upload from URL. This manual is specific to a Ford Freestar. RepairSurge is compatible with any internet-enabled computer, laptop, smartphone or tablet device. It is very easy to use and support is always free. We wish we could just show you the entire manual before you buy, but our publishing agreement with the auto manufacturers prevents this. We know this sounds crazy. It's a stupid rule in our opinion, but they authorize our manuals and that's what their lawyers require. Here are some of the comments we have received from users of RepairSurge. These customers have agreed to allow us to publicly display their testimonials. We know buying anything online is a risk. Once again, we wish we could just show you the entire manual before you buy, but our publishing agreement with the auto manufacturers prevents this. We'll get you the repair information you need, every time, or your money back. Manufacturer: Ford. Model: Freestar. Production Year: Step by Step Instructions. Comprehensive Diagrams. Diagnostic Procedures. Wiring Diagrams. Here is what you'll get. Step-by-step factory recommended repair instructions. Unlimited access to personal support reps who are always available to assist you. We can answer your questions about using the software or help you find the specific information you need for your Ford Freestar. Free real-time updates! Your manual is updated with revised information as soon as it is released. Access on your terms. Unlimited access to your Ford Freestar manual on a yearly basis. We'll get you the repair information you need, every time, or we'll refund your purchase in full. Can I see what the manual looks like? See our guarantee below. You are protected in case the manual turns out to not be what you need. What Satisfied Mechanics Are Saying. Exactly as advertised, quick and easy transaction. Get Your Manual. Your satisfaction is guaranteed and your online transaction is protected by safe and secure SSL encryption technology. Skip to main content. Email to friends Share on Facebook - opens in a new window or tab Share on Twitter - opens in a new window or tab Share on Pinterest - opens in a new window or tab. Add to Watchlist. People who viewed this item also viewed. Showing Slide 1 of 1 - Carousel. Check if this part fits your vehicle. Contact the seller. Picture Information. Mouse over to Zoom - Click to

enlarge. Get the item you ordered or get your money back. Learn more - eBay Money Back Guarantee - opens in new window or tab. Seller information colanded Contact seller. See other items More See all. Item Information Condition:. Sign in to check out Check out as guest. Make Offer. Resume making your offer , if the page does not update immediately. Add to Watchlist Remove from watch list. Watch list is full. Longtime Member. May not ship to Ukraine - Read item description or contact seller for shipping options. See details. Item location:. Frisco, Texas, United States. Ships to:. This amount is subject to change until you make payment. For additional information, see the Global Shipping Program terms and conditions - opens in a new window or tab This amount includes applicable customs duties, taxes, brokerage and other fees. For additional information, see the Global Shipping Program terms and conditions - opens in a new window or tab. Any international shipping is paid in part to Pitney Bowes Inc. Learn More - opens in a new window or tab International shipping and import charges paid to Pitney Bowes Inc. Learn More - opens in a new window or tab Any international shipping and import charges are paid in part to Pitney Bowes Inc. Learn More - opens in a new window or tab Any international shipping is paid in part to Pitney Bowes Inc. Learn More - opens in a new window or tab. Related sponsored items. Showing Slide 1 of 2 - Carousel. Report item - opens in a new window or tab. This translation tool is for your convenience only. The accuracy and accessibility of the resulting translation is not guaranteed. Note: The accuracy and accessibility of the resulting translation is not guaranteed. Seller assumes all responsibility for this listing. Condition is "Used". Shipping and handling. The seller has not specified a shipping method to Ukraine. Contact the seller - opens in a new window or tab and request shipping to your location. Shipping cost cannot be calculated. Please enter a valid ZIP Code. Shipping to: United States. No additional import charges at delivery! This item will be shipped through the Global Shipping Program and includes international tracking. Learn more - opens in a new window or tab. There are 1 items available. Please enter a number less than or equal to 1. Select a valid country. Please enter 5 or 9 numbers for the ZIP Code. Domestic handling time. Taxes may be applicable at checkout. Learn more. Return policy. No returns or exchanges, but item is covered by the eBay Money Back Guarantee - opens in a new window or tab. Payment details. Payment methods. Back to home page Return to top. Back to home page. Listed in category:. Email to friends Share on Facebook - opens in a new window or tab Share on Twitter - opens in a new window or tab Share on Pinterest - opens in a new window or tab Add to Watchlist. Image not available Photos not available for this variation. Change country: -Select- United States There are 1 items available. Slideshare uses cookies to improve functionality and performance, and to provide you with relevant advertising. If you continue browsing the site, you agree to the use of cookies on this website. See our User Agreement and Privacy Policy. See our Privacy Policy and User Agreement for details. Published on Jun 11, It is this level of detail, along with hundreds of photos and illustrations, that guide the reader through each service and repair procedure. Complete download comes in pdf format which can work under all PC based windows operating system and Mac also, All pages are printable. Using this repair manual is an inexpensive way to keep your vehicle working properly. SlideShare Explore Search You. Submit Search. Home Explore. Successfully reported this slideshow. We use your LinkedIn profile and activity data to personalize ads and to show you more relevant ads. You can change your ad preferences anytime. Upcoming SlideShare. Like this document? Why not share! Embed Size px. Start on. Show related SlideShares at end. WordPress Shortcode. Published in: Automotive. Full Name Comment goes here. Are you sure you want to Yes No. No Downloads. Views Total views. Actions Shares. No notes for slide. Thank you very much for your reading. You just clipped your first slide! Clipping is a handy way to collect important slides you want to go back to later. Now customize the name of a clipboard to store your clips. Visibility Others can see my Clipboard. Cancel Save. JavaScript seems to be disabled in your browser. For the best experience on our site, be sure to turn on Javascript in your browser. ZIP Toggle Nav. Your credit card details are proccessed using the latest encryption software. Do not miss out on your download. Check your email address is correct. Helena St. Lucia St. Martin St. Outlying Islands U. Please select a region, state or province. Skip to the end of the images gallery. Skip to the beginning of the images gallery. If you need a repair manual for your Ford, you've come to the right place. Now you can get your repair manual in a convenient digital format. Old paper repair manuals just don't compare! This downloadable repair manual software covers the Ford Freestar and is perfect for any do-it-yourselfer. In the dark old days of auto repair,

fiesta haynes manual

dual radio xdm260

wattstopper occupancy sensor wiring diagram

you had to buy a traditional service manual in book format which would retail at a higher cost.

Getting the same information in digital format is so much less expensive and more convenient! Maybe you need the manual to fix the brakes on your Freestar, or possibly replace some worn out suspension components. Or you might need to get your engine running, or just do the required standard maintenance. Whatever the case may be, this repair manual software for the Ford Freestar is just what you need. You will have all the service information you could ever need for your vehicle. It will help you fix the brakes, engine, suspension, steering, drivetrain, electrical problems, heat, air conditioning, etc. Anything can be fixed! You can save a lot of money by working on your own vehicle. You probably already know this, but mechanics charge a lot. Do it yourself and use this Ford Freestar repair manual software to guide the way. It gives you the manual for your Freestar and it's very easy to use.